

# **Operator's Manual**



### **Optris GmbH**

Ferdinand-Buisson-Str. 14 13127 Berlin Germany

Tel.: +49 30 500 197-0 Fax: +49 30 500 197-10

E-mail: info@optris.de Internet: www.optris.de



# **Table of Contents**

T	able of (	Contents	3
1		eral Informationeral	
	1.1	Description	7
	1.2	Warranty	8
	1.3	Scope of Supply	8
	1.4	Maintenance	9
	1.5	Model Overview	10
	1.6	Factory Default Settings	11
2	Tecl	hnical Data	13
	2.1	General Specifications	13
	2.2	Electrical Specifications	14
	2.3	Measurement Specifications [1M models]	15
	2.4	Measurement Specifications [2M models]	16

4		<b>♦</b> optris
	2.5	Measurement Specifications [3M models]
	2.6	Optical Charts
3	Мес	hanical Installation21
4	Acc	essories24
	4.1	Air Purge Collar
	4.2	Mounting Bracket
	4.3	Water Cooled Housing
	4.4	Rail Mount Adapter for Electronic box
5	Elec	trical Installation28
	5.1	Cable Connections
	5.2	Ground Connection
	5.3	Sensing head Calibration Code
6	Outp	outs and Inputs34
	6.1	Analog Output

T	able of C	ontents 5
	6.2	Digital Interface
	6.3	Functional Inputs
	6.4	Alarms
7	Ope	rating
	7.1	Sensor Setup
8	Sigh	ting43
	8.1	Focusing and Video Sighting
	8.2	Error messages
9	Soft	ware CompactConnect46
	9.1	Installation
	9.2	Communication Settings
10	Basi	cs of Infrared Thermometry49
11	Emis	ssivity50
	11.1	Definition

6		*optris
11.2	Determination of unknown Emissivities	50
11.3	Characteristic Emissivities	51
Appendi	ix A – Emissivity Table Metals	52
Appendi	ix B – Emissivity Table Non Metals	54
Appendi	ix C – Smart Averaging	55
Appendi	ix D – Declaration of Conformity	56

General Information 7

### 1 General Information

## 1.1 Description

Thank you for choosing the **optris® CTvideo** infrared thermometer.

The sensors of the optris CTvideo series are noncontact infrared temperature sensors.

They calculate the surface temperature based on the emitted infrared energy of objects [►10 Basics of Infrared Thermometry]. The alignment of the sensor can be done with the integrated video sighting and crosshair laser aiming.

The sensor housing of the CTvideo head is made of stainless steel (IP65/ NEMA-4 rating) – the sensor electronics is placed in a separate box made of die casting zinc.



The CTvideo sensing head is a sensitive optical system. Please use only the thread for mechanical installation.



- Avoid abrupt changes of the ambient temperature.
- Avoid mechanical violence on the head this may destroy the system (expiry of warranty).
- If you have any problems or questions, please contact our service department.



Read the manual carefully before the initial start-up. The producer reserves the right to change the herein described specifications in case of technical advance of the product.

8 \$\phi\text{optris}\$



▶ All accessories can be ordered according to the referred part numbers in brackets [ ].

### 1.2 Warranty

Each single product passes through a quality process. Nevertheless, if failures occur please contact the customer service at once. The warranty period covers 24 months starting on the delivery date. After the warranty is expired the manufacturer guarantees additional 6 months warranty for all repaired or substituted product components. Warranty does not apply to damages, which result from misuse or neglect. The warranty also expires if you open the product. The manufacturer is not liable for consequential damage or in case of a non-intended use of the product.

If a failure occurs during the warranty period the product will be replaced, calibrated or repaired without further charges. The freight costs will be paid by the sender. The manufacturer reserves the right to exchange components of the product instead of repairing it. If the failure results from misuse or neglect the user has to pay for the repair. In that case you may ask for a cost estimate beforehand.

## 1.3 Scope of Supply

- CTvideo sensing head with connection cable and electronic box
- Mounting nut and mounting bracket (fixed)
- 5 m USB cable
- Software CompactConnect
- Operators manual

General Information

#### 1.4 Maintenance

**Lens cleaning:** Blow off loose particles using clean compressed air. The lens surface can be cleaned with a soft, humid tissue moistened with water or a water based glass cleaner.



Never use cleaning compounds which contain solvents (neither for the lens nor for the housing).

10 **\$**optris

### 1.5 Model Overview

The sensors of the CTvideo series are available in the following basic versions:

Model	Model code	Measurement range	Spectral response	Typical applications		
	1ML	485 to 1050 °C				
CT video 1M	1MH	650 to 1800 °C	1,0 µm	Metals and ceramic surfaces		
	1MH1	800 to 2200 °C				
	2ML	250 to 800 °C		Metals and ceramic surfaces		
CT video 2M	2MH	385 to 1600 °C	1,6 µm			
	2MH1	490 to 2000 °C				
	3ML	50 to 400 °C				
	ЗМН	100 to 600 °C				
CT video 3M	3MH1	150 to 1000 °C	2,3 μm	Metals at low object temperatures (ab 50 °C)		
	3MH2	200 to 1500 °C				
	3MH3	250 to 1800 °C				

In the following chapters of this manual you will find only the short model codes.

On the 1M, 2M, 3M models the whole measurement range is split into several sub ranges (L, H, H1 etc.).

General Information

# 1.6 Factory Default Settings

The unit has the following presetting at time of delivery:

Signal output object temperature	0-5 V								
Emissivity	1,000								
Transmissivity	1,000								
Average time (AVG)	inactive								
Smart Averaging	Smart Averaging active								
Peak hold	inactive								
Valley hold	inactive								
	1ML	1MH	1MH1	2ML	2MH	2MH1	3ML	ЗМН	3MH1
Lower limit temperature range [°C]	485	650	800	250	385	490	50	100	150
Upper limit temperature range [°C]	1050	1800	2200	800	1600	2000	400	600	1000
Lower alarm limit [°C] (normally closed)	600	800	1200	350	500	800	100	250	350
Upper alarm limit [°C] (normally open)	900	1400	1600	600	1200	1400	300	500	600

12 **\$\phi**ptris\$

	3MH2	3MH3
Lower limit temperature range [°C]	200	250
Upper limit temperature range [°C]	1500	1800
Lower alarm limit [°C] (normally closed)	550	750
Upper alarm limit [°C] (normally open)	1000	1200
Lower limit signal output	0 V	
Upper limit signal output	5 V	
Temperature unit	°C	
Ambient temperature compensation	internal	head temp
Baudrate [kBaud]	115	
Laser	inactive	



**Smart Averaging** means a dynamic average adaptation at high signal edges. [Activation via software only].

► Appendix C - Smart Averaging

Technical Data

## 2 Technical Data

# 2.1 General Specifications

	Sensing head	Electronic box			
Environmental rating	IP65 (NEMA-4)				
Ambient temperature 1)	-2070 °C	-2085 °C			
Storage temperature	-40	85 °C			
Relative humidity	1095 %, no	n condensing			
Material	stainless steel	die casting zinc			
Dimensions	116 mm x 50 mm, M48x1,5	89 mm x 70 mm x 30 mm			
Weight	600 g	420 g			
Cable length	3 m (standard), 5 m, 10 m				
Cable diameter	5 mm				
Ambient temperature cable					
Cable sensing head-electronics USB-cable	max. 80 °C [High temperature cable (optional): 180 °C] max. 80 °C				
Vibration	IEC 68-2-6: 3G, 11 – 200 Hz, any axis				
Shock	IEC 68-2-27: 50G, 11 ms, any axis				
Software (optional)	CompactConnect				

<sup>&</sup>lt;sup>1)</sup> Laser will turn off automatically at ambient temperatures >50 °C. The functionality of the LCD display can be limited at ambient temperatures below 0 °C.

14 optris

# 2.2 Electrical Specifications

Power Supply	8–36 VDC					
Current draw	max. 160 mA					
Aiming laser	635 nm, 1 mW, On/ Off via programming keys or software					
Video sighting	Digital (USB 2.0), 640 x 480 px, FOV 3.1° x 2.4°					
Output/ analog	selectable: 0/ 4–20 mA, 0–5/ 10 V, thermocouple (J or K) or alarm output (Signal source: object temperature)					
Alarm output	Open collector output at Pin AL2 [24 V/ 50 mA]					
Output impedances						
mA mV Thermocouple	max. loop resistance 500 $\Omega$ (at 8-36 VDC) min. 100 $k\Omega$ load impedance 20 $\Omega$					
Digital interface	USB 2.0					
Functional inputs	<ul> <li>F1-F3; software programmable for the following functions:</li> <li>external emissivity adjustment</li> <li>ambient temperature compensation</li> <li>trigger (reset of hold functions)</li> </ul> Input impedance F2 and F3: 43 kΩ					

Technical Data

# 2.3 Measurement Specifications [1M models]

	1ML	1MH	1MH1			
Temperature range (scalable)	4851050 °C	6501800 °C	8002200 °C			
Spectral range		1,0 µm				
Optical resolution	150:1	300	0:1			
System accuracy 1), 2), 3)	±(0,3 % of reading +2 °C)					
Repeatability 1), 3)	±(0,1 % of reading +1 °C)					
Temperature resolution (NETD)	0,1 K					
Exposure time (90% signal) 4)	1 ms					
Emissivity/ Gain	0,1001,100 (adjustable via programming keys or software)					
Transmissivity	0,1001,100 (adjustable via programming keys or software)					
Signal processing	Average, peak hold, valley hold (adjustable via programming keys or software)					

 $<sup>^{1)}</sup>$  at ambient temperature 23±5 °C  $^{2)}$  Accuracy for thermocouple output: ±2,5 °C or ±1 %  $^{3)}$   $\epsilon$  = 1/ Response time 1 s  $^{4)}$  with dynamic adaptation at low signal levels

16 **+**optris

# 2.4 Measurement Specifications [2M models]

	2ML	2MH	2MH1			
Temperature range (scalable)	250800 °C	3851600 °C	4902000 °C			
Spectral range	1,6 µm					
Optical resolution	150:1 300:1					
System accuracy 1), 2), 3)	±(0,3 % of reading +2 °C)					
Repeatability 1), 3)	±(0,1 % of reading +1 °C)					
Temperature resolution (NETD)	0,1 K					
Exposure time (90% signal) 4)	1 ms					
Emissivity/ Gain	0,1001,100 (adjustable via programming keys or software)					
Transmissivity	0,1001,100 (adjustable via programming keys or software)					
Signal processing	Average, peak hold, valley	hold (adjustable via program	mming keys or software)			

 $<sup>^{1)}</sup>$  at ambient temperature 23±5 °C  $^{2)}$  Accuracy for thermocouple output: ±2,5 °C or ±1 %  $^{3)}$   $\epsilon$  = 1/ Response time 1 s  $^{4)}$  with dynamic adaptation at low signal levels

Technical Data

# 2.5 Measurement Specifications [3M models]

	3ML	3МН	3MH1	3MH2	3MH3		
Temperature range (scalable)	50400 °C 1)	100600 °C 1)	1501000 °C	2001500 °C	2501800 °C		
Spectral range		2,3 µm					
Optical resolution	60:1	100:1 300:1					
System accuracy <sup>2), 3), 4)</sup>	±(0,3 % of reading +2 °C)						
Repeatability <sup>2), 4)</sup>	±(0,1 % of reading +1 °C)						
Temperature resolution (NETD) 4)	0,1 K						
Exposure time (90 % signal) 5)	1 ms						
Emissivity/ Gain	0,1001,100 (adjustable via programming keys or software)						
Transmissivity	0,1001,100 (adjustable via programming keys or software)						
Signal processing	Average, peak hold, valley hold (adjustable via programming keys or software)						

 $<sup>^{1)}</sup>$  TObject > THead+25 °C  $^{2)}$  at ambient temperature 23±5 °C  $^{3)}$  Accuracy for thermocouple output: ±2,5 °C or ±1 %  $^{4)}$   $\epsilon$  = 1/ Response time 1 s  $^{5)}$  with dynamic adaptation at low signal levels

18 +optris

## 2.6 Optical Charts

The vario optics of the CTvideo allows a smooth focusing of the optics to the desired distance. The sensors are available in two optic versions:

Optics	Focus adjustable in the range
SFV	200 mm till infinity
CFV	90 mm till 250 mm

**(i)** 

The size of the measuring object and the optical resolution of the infrared thermometer determine the maximum distance between sensing head and measuring object.

In order to prevent measuring errors the object should fill out the field of view of the optics completely.

Consequently, the spot should at all times have at least **the same size** like the object or should be **smaller than** that.

The following tables show the diameter of the measuring spot for some selected distances. The spot size refers to 90 % of the radiation energy.

The distance is always measured from the front edge of the sensing head.

As an alternative to the optical diagrams, the spot size calculator can also be used on the optris website <a href="http://www.optris.com/spot-size-calculator">http://www.optris.com/spot-size-calculator</a>.

Technical Data 19

spot size         mm         3,3         5,0         7,5         11,7         18,3         26,7         41,7         83,3           measurement distance         mm         200         300         450         700         1100         1600         2500         5000           3ML: CF optics (D:S=60:1)           spot size         mm         1,5         2,0         2,5         3,0         3,5         4,2           measurement distance         mm         2,0         3,0         4,5         7,0         11,0         16,0         25,0         50,0           3MH: SF optics (D:S=100:1)           spot size         mm         2,0         3,0         4,5         7,0         11,0         16,0         25,0         50,0           3MH: CF optics (D:S=100:1)           spot size         mm         0,9         1,2         1,5         1,8         2,1         2,5           measurement distance         mm         0,9         1,2         1,5         1,8         2,1         2,5           measurement distance         mm         1,3         2,0         3,0         4,7         7,3         10,7         16,7	ONL OF 15 1/0 00 4)						1			
Marie   Mari	3ML: SF optics (D:S=60:1)									
3ML: CF optics (D:S=60:1) spot size	spot size	mm	3,3	5,0	7,5	11,7	18,3	26,7	41,7	83,3
Spot size   mm   1,5   2,0   2,5   3,0   3,5   4,2	measurement distance	mm	200	300	450	700	1100	1600	2500	5000
Spot size   mm   1,5   2,0   2,5   3,0   3,5   4,2										
MH: SF optics (D:S=100:1)   Spot size   mm   2,0   3,0   4,5   7,0   11,0   16,0   25,0   50,0	3ML: CF optics (D:S=60:1)	1								
3MH: SF optics (D:S=100:1) spot size	spot size	mm	1,5	2,0	2,5	3,0	3,5	4,2		
spot size         mm         2,0         3,0         4,5         7,0         11,0         16,0         25,0         50,0           measurement distance         mm         200         300         450         700         1100         1600         25,0         50,0           3MH: CF optics (D:S=100:1)           spot size         mm         0,9         1,2         1,5         1,8         2,1         2,5           measurement distance         mm         90         120         150         180         210         250           1ML/2ML: SF optics (D:S=150:1)           spot size         mm         1,3         2,0         3,0         4,7         7,3         10,7         16,7         33,3           measurement distance         mm         200         300         450         700         1100         1600         2500         5000           1ML/2ML: CF optics (D:S=150:1)           spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7	measurement distance	mm	90	120	150	180	210	250		
spot size         mm         2,0         3,0         4,5         7,0         11,0         16,0         25,0         50,0           measurement distance         mm         200         300         450         700         1100         1600         25,0         50,0           3MH: CF optics (D:S=100:1)           spot size         mm         0,9         1,2         1,5         1,8         2,1         2,5           measurement distance         mm         90         120         150         180         210         250           1ML/2ML: SF optics (D:S=150:1)           spot size         mm         1,3         2,0         3,0         4,7         7,3         10,7         16,7         33,3           measurement distance         mm         200         300         450         700         1100         1600         2500         5000           1ML/2ML: CF optics (D:S=150:1)           spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7		<del>-</del>	- · · · · ·							
measurement distance         mm         200         300         450         700         1100         1600         2500         5000           3MH: CF optics (D:S=100:1)           spot size         mm         0,9         1,2         1,5         1,8         2,1         2,5           measurement distance         mm         90         120         150         180         210         250           1ML/2ML: SF optics (D:S=150:1)           spot size         mm         1,3         2,0         3,0         4,7         7,3         10,7         16,7         33,3           1ML/2ML: CF optics (D:S=150:1)           spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7	3MH: SF optics (D:S=100:	3MH: SF optics (D:S=100:1)								
3MH: CF optics (D:S=100:1) spot size	spot size	mm	2,0	3,0	4,5	7,0	11,0	16,0	25,0	50,0
spot size         mm         0,9         1,2         1,5         1,8         2,1         2,5           measurement distance         mm         90         120         150         180         210         250           1ML/2ML: SF optics (D:S=150:1)           spot size         mm         1,3         2,0         3,0         4,7         7,3         10,7         16,7         33,3           measurement distance         mm         200         300         450         700         1100         1600         2500         5000           1ML/2ML: CF optics (D:S=150:1)           spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7	measurement distance	mm	200	300	450	700	1100	1600	2500	5000
spot size         mm         0,9         1,2         1,5         1,8         2,1         2,5           measurement distance         mm         90         120         150         180         210         250           1ML/2ML: SF optics (D:S=150:1)           spot size         mm         1,3         2,0         3,0         4,7         7,3         10,7         16,7         33,3           measurement distance         mm         200         300         450         700         1100         1600         2500         5000           1ML/2ML: CF optics (D:S=150:1)           spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7										
measurement distance         mm         90         120         150         180         210         250           1ML/2ML: SF optics (D:S=150:1)           spot size         mm         1,3         2,0         3,0         4,7         7,3         10,7         16,7         33,3           measurement distance         mm         200         300         450         700         1100         1600         2500         5000           1ML/2ML: CF optics (D:S=150:1)           spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7	3MH: CF optics (D:S=100:1)									
1ML/2ML: SF optics (D:S=150:1)         spot size       mm       1,3       2,0       3,0       4,7       7,3       10,7       16,7       33,3         measurement distance       mm       200       300       450       700       1100       1600       2500       5000         1ML/2ML: CF optics (D:S=150:1)         spot size       mm       0,6       0,8       1,0       1,2       1,4       1,7	spot size	mm	0,9	1,2	1,5	1,8	2,1	2,5		
spot size         mm         1,3         2,0         3,0         4,7         7,3         10,7         16,7         33,3           measurement distance         mm         200         300         450         700         1100         1600         2500         5000           1ML/2ML: CF optics (D:S=150:1)           spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7	measurement distance	mm	90	120	150	180	210	250		
spot size         mm         1,3         2,0         3,0         4,7         7,3         10,7         16,7         33,3           measurement distance         mm         200         300         450         700         1100         1600         2500         5000           1ML/2ML: CF optics (D:S=150:1)           spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7							·			
measurement distance         mm         200         300         450         700         1100         1600         2500         5000           1ML/2ML: CF optics (D:S=150:1)           spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7	1ML/2ML: SF optics (D:S=	1ML/2ML: SF optics (D:S=150:1)								
1ML/2ML: CF optics (D:S=150:1) spot size mm 0,6 0,8 1,0 1,2 1,4 1,7	spot size	mm	1,3	2,0	3,0	4,7	7,3	10,7	16,7	33,3
spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7	measurement distance	mm	200	300	450	700	1100	1600	2500	5000
spot size         mm         0,6         0,8         1,0         1,2         1,4         1,7										
	1ML/2ML: CF optics (D:S=150:1)									
measurement distance   mm   90   120   150   180   210   250	spot size	mm	0,6	0,8	1,0	1,2	1,4	1,7		
	measurement distance	mm	90	120	150	180	210	250		

**\$**optris


1MH-H1/2MH-H1/3MH1-H3: SF optics (D:S=300:1)									
spot size	mm	0,7	1,0	1,5	2,3	3,7	5,3	8,3	16,7
measurement distance	mm	200	300	450	700	1100	1600	2500	5000

1MH-H1/2MH-H1/3MH1-H3: CF optics (D:S=300:1)							
spot size	mm	0,3	0,4	0,5	0,6	0,7	0,8
measurement distance	mm	90	120	150	180	210	250

Mechanical Installation 21

### 3 Mechanical Installation

The CTvideo is equipped with a metric M48x1,5 thread and can be installed either directly via the sensor thread or with help of the supplied mounting nut (standard) and fixed mounting bracket (standard) to a mounting device available.




CTvideo sensing head (Basic version)




Make sure to keep the optical path clear of any obstacles.


22 **\$**optris



CTvideo sensing head (High temperature version)

Mechanical Installation 23







Electronic box



For an exact alignment of the head to the object please activate the integrated video and/ or crosshair laser sighting.

[▶7 Operating, 8 Sighting]


Mounting bracket, adjustable in one axis [ACCTLFB] - standard scope of supply

24 \$\phi\text{optris}\$

### 4 Accessories

### 4.1 Air Purge Collar

The lens must be kept clean at all times from dust, smoke, fumes and other contaminants in order to avoid reading errors. These effects can be reduced by using an air purge collar. Make sure to use oil-free, technically clean air, only.





The needed amount of air (approx. 2...10 l/ min.) depends on the application and the installation conditions on-site.



Air purge collar [ACCTLAP] Hose connection: 6x8 mm Thread (fitting): G 1/8 inch Accessories 25

# 4.2 Mounting Bracket








Mounting bracket, adjustable in two axes [ACCTLAB]

This adjustable mounting bracket allows an adjustment of the sensor in two axis.

26 optris

### 4.3 Water Cooled Housing



To avoid condensation on the optics an air purge collar is recommended.

Water flow rate: approx. 2 l/ min (Cooling water temperature should not exceed 30 °C)




Water cooled housing [ACCTLW] Hose connection: 6x8 mm Thread (fitting): G 1/8 inch

The sensing head can be used at ambient temperatures up to 70 °C without cooling. For applications, where the ambient temperature can reach higher values, the usage of the optional water cooled housing is recommended (operating temperature up to 175 °C). The sensor should be equipped with the optional high temperature cables (operating temperature up to 180 °C).

Accessories 27

## 4.4 Rail Mount Adapter for Electronic box

With the rail mount adapter the CTvideo electronics can be mounted easily on a DIN rail (TS35) according EN50022.





Rail mount adapter [ACCTRAIL]



▶ All accessories can be ordered according to the referred part numbers in brackets [ ].

28 \$\phi\text{optris}\$

### 5 Electrical Installation

#### 5.1 Cable Connections

The CTvideo sensing heads are equipped with connectors in the backplane. Therefore an opening of the sensing head for assembling or disassembling is not necessary. An USB cable (5 m) is already connected on the electronics and can be used for linking to a computer.

#### **Basic version**

The standard version of the CTvideo has a 12-pin connector which is integrated in the sensors backplane. The connection to the electronics is done by the blue sensor cable. Cable lengths of 3 m, 5 m and 10 m are available.




#### **High temperature version**


The high temperature version of the CTvideo has two connectors (7-pin and 5-pin) which are integrated in the sensor backplane. The connection sensing head – electronics will be done in this case via: a 7-core high temperature cable (sensor signals, laser) and a 4-core high temperature cable (video signal). Cable lengths of 3 m, 5 m and 10 m are available.



Electrical Installation 29



**CTvideo Basic version** 



CTvideo High temperature version

30 optris

#### Designation

+8..36 VDC Power supply

GND Ground (0 V) of power supply GND Ground (0 V) of internal in- and outputs

AL2 Alarm 2 (Open collector output)
OUT-TC Analog output thermocouple (J or K)

OUT-mV/mA Analog output object temperature (mV or mA)

F1-F3 Functional inputs
GND Ground (0 V)

3V SW BLACK/ Power supply Laser (+)

GND GREY/ Ground Laser (–)

**ORANGE** Temperature probe head (NTC)

BLUE Head ground
PURPLE Head power
YELLOW Detector signal



Opened electronic box with terminal connections

### **Power supply**

Please use a separate, stabilized power supply unit with an output voltage of **8–36 VDC** which can supply **160 mA**. The ripple should be max. **200 mV**.

Please use shielded cables only for all power and data lines.

The sensor shield has to be grounded.





Please do never connect a supply voltage to the analog outputs as this will destroy the output!

The CTvideo is not a 2-wire sensor!

Electrical Installation 31


### Cable Assembling

The cable gland M12x1,5 allows the use of cables with a diameter of 3 to 5 mm.

Remove the isolation from the cable (40 mm power supply, 50 mm signal outputs, 60 mm functional inputs). Cut the shield down to approximately 5 mm and spread the strands out. Extract about 4 mm of the wire isolation and tin the wire ends.

Place the pressing screw, the rubber washer and the metal washers of the cable gland one after the other onto the prepared cable end. Spread the strands and fix the shield between two of the metal washers. Insert the cable into the cable gland until the limit stop. Screw the cap tight.

Every single wire may be connected to the according screw clamps according to their colors.






Use shielded cables only. The sensor shield has to be grounded.

32 +optris

#### 5.2 Ground Connection

At the bottom side of the mainboard PCB you will find a connector (jumper) which has been placed from factory side as shown in the picture [bottom and middle pin connected]. In this position the ground connections (GND power supply/ outputs) are connected with the ground of the electronics housing. To avoid ground loops and related signal interferences in industrial environments it might be necessary to interrupt this connection. To do this please put the jumper in the opposite position [middle and top pin connected].

If the thermocouple output is used the connection GND – housing should be interrupted generally.



CTvideo mainboard

Electrical Installation 33

## 5.3 Sensing head Calibration Code

Every head has a specific calibration code, which is printed on the head. For a correct temperature measurement and functionality of the sensor this calibration code must be stored into the electronic box. The calibration code consists of five blocks with 4 characters each.

Example: **EKJ0 – 00UD – 0A1B – A17U – 930Z** 

block1 block2 block3 block4 block5

For entering the code please press the **Up** and **Down** key (keep pressed) and then the **Mode** key. The display shows **HCODE** and then the 4 signs of the first block. With **Up** and **Down** each sign can be changed, **Mode** switches to the next sign or next block.



After you have modified the head code a reset is necessary to activate the change.

[▶7 Operating]





You will find the calibration code on a label fixed on the head. Please do not remove this label or make sure the code is noted anywhere.

34 +optris

# 6 Outputs and Inputs

## **6.1 Analog Output**

This output is used for the object temperature. The selection of the output signal can be done via the programming keys [▶7 Operating]. The CompactConnect software allows the programming of output channel 1 as an alarm output.

Output signal	Range	Connection pin on CTvideo board
Voltage	0 5 V	OUT-mV/mA
Voltage	0 10 V	OUT-mV/mA
Current	0 20 mA	OUT-mV/mA
Current	4 20 mA	OUT-mV/mA
Thermocouple	TC J	OUT-TC
Thermocouple	TC K	OUT-TC




According to the chosen output signal there are different connection pins on the mainboard (OUT-mV/mA or OUT-TC).

Outputs and Inputs 35

## 6.2 Digital Interface

The CTvideo sensors are equipped with an USB interface. The interface board is located beside the LCD display. To uninstall the board please disconnect both of the M3x5 screws. Please pay attention to the correct positioning of the pin strip if you install the board.



## **6.3 Functional Inputs**

The three functional inputs F1 – F3 can be programmed with the CompactConnect software, only.

**F1 (digital):** trigger (a 0 V level on F1 resets the hold functions)

F2 (analog): external emissivity adjustment [0–10 V: 0 V  $\triangleright$   $\epsilon$ =0,1; 9 V  $\triangleright$   $\epsilon$ =1; 10 V  $\triangleright$   $\epsilon$ =1,1] F3 (analog): external compensation of ambient temperature/ the range is scalable via software

[0-10 V ▶ -40-900 °C / preset range: -20-200 °C]

F1-F3 (digital): emissivity (digital choice via table)

A non connected input represents:

F1=High | F2, F3=Low.

[High level: ≥ +3 V...+36 V | Low level: ≤ +0,4 V...-36 V]

36 +optris

#### 6.4 Alarms

The CTvideo has the following Alarm features:

All alarms (alarm 1, alarm 2, output channel 1 and 2 if used as alarm output) have a fixed **hysterese of 2 K**.

#### **Output channel 1**

To activate the alarm function the output channel has to be switched into digital mode. For this purpose the software CompactConnect is required.

#### Visual Alarms

These alarms will cause a change of the color of the LCD display and will also change the status of the optional relays interface. In addition the Alarm 2 can be used as open collector output at pin AL2 on the mainboard [24 V/ 50 mA].

From factory side the alarms are defined as follows:

Alarm 1 Norm. closed/ Low-Alarm Alarm 2 Norm. open/ High-Alarm

Both of these alarms will have effect on the LCD color:

BLUE: alarm 1 active
RED: alarm 2 active
GREEN: no alarm active

Extended setup like definition as low or high alarm [via change of normally open/ closed], selection of the signal source [ $T_{Obj}$ ,  $T_{Head}$ ,  $T_{Box}$ ] can be done with the software CompactConnect.


Operating 37

# 7 Operating

After power up the unit the sensor starts an initializing routine for some seconds. During this time the display will show **INIT**. After this procedure the object temperature is shown in the display. The display backlight color changes according to the alarm settings [▶6.4 Alarms].

### 7.1 Sensor Setup

The programming keys Mode, Up and Down enable the user to set the sensor on-site. The current measuring value or the chosen feature is displayed. With Mode the operator obtains the chosen feature, with Up and Down the functional parameters can be selected — a change of parameters will have immediate effect. If no key is pressed for more than 10 seconds the display automatically shows the calculated object temperature (according to the signal processing).



Pressing the Mode button again recalls the last called function on the display. The signal processing features **Peak hold** and **Valley hold** cannot be selected simultaneously.

#### **Factory Default Setting**

To set the CTvideo back to the factory default settings, please press at first the **Down**-key and then the **Mode**-key and keep both pressed for approx. 3 seconds.

The display will show **RESET** for confirmation.

**\$**optris

Display	Mode [Sample]	Adjustment Range		
SON	Laser Sighting [On]	ON/ OFF		
142.3C	Object temperature (after signal processing) [142,3 °C]	fixed		
127CH	Head temperature [127 °C]	fixed		
25CB	Box temperature [25 °C]	fixed		
142CA	Current object temperature [142 °C]	fixed		
□ MV5	Signal output channel 1 [0-5 V]	□ <b>0-20</b> = 0–20 mA/ □ <b>4-20</b> = 4–20 mA/ □ <b>MV5</b> = 0–5 V/		
		$\square$ <b>MV10</b> = 0-10 V/ $\square$ <b>TCJ</b> = thermocouple type J/		
		☐ <b>TCK</b> = thermocouple type K		
E0.970	Emissivity [0,970]	0,100 1,100		
T1.000	Transmissivity [1,000]	0,100 1,100		
A 0.2	Signal output Average [0,2 s]	A = inactive/ 0,1 999,9 s		
P	Signal output Peak hold [inactive]	P = inactive/ 0,1 999,9 s/ P oo oo oo oo = infinite		
V	Signal output Valley hold [inactive]	V = inactive/ 0,1 999,9 s/ V oo oo oo oo = infinite		
u 0.0	Lower limit temperature range [0 °C]	depending on model/ inactive at TCJ- and TCK-output		
n 500.0	Upper limit temperature range [500 °C]	depending on model/ inactive at TCJ- and TCK-output		
0.00	Lower limit signal output [0 V]	according to the range of the selected output signal		
] 5.00	Upper limit signal output [5 V]	according to the range of the selected output signal		
U °C	Temperature unit [°C]	°C/ °F		
30.0	Lower alarm limit [30 °C]	depending on model		
100.0	Upper alarm limit [100 °C]	depending on model		
XHEAD	Ambient temperature compensation [head temperature]	XHEAD = head temperature/ -40,0 900,0 °C (for LT) as		
		fixed value for compensation/ returning to XHEAD (head		
		temperature) by pressing <b>Up</b> and <b>Down</b> together		
M 01	Multidrop adress [1] (only with RS485 interface)	01 32		
B 9.6	Baud rate in kBaud [9,6]	9,6/ 19,2/ 38,4/ 57,6/ 115,2 kBaud		

Operating 39 S ON Activating (ON) and Deactivating (OFF) of the Sighting Laser. By pressing Up or Down the laser can be switched on and off. □ MV5 Selection of the **Output signal**. By pressing **Up** or **Down** the different output signals can be selected (see table). Setup of **Emissivity**. Pressing **Up** increases the value, **Down** decreases the value (also E0.970 valid for all further functions). The emissivity is a material constant factor to describe the ability of the body to emit infrared energy [►11 Emissivity]. T1.000 Setup of **Transmissivity**. This function is used if an optical component (protective window, additional optics e.g.) is mounted between sensor and object. The standard setting is 1.000 = 100 % (if no protective window etc. is used). A 0.2 Setup of Average time. In this mode an arithmetic algorithm will be performed to smoothen the signal. The set time is the time constant. This function can be combined with all other post processing functions. The shortest value is 0,001 s and can be increased/ decreased only by values of the power series of 2 (0,002, 0,004, 0,008, 0,016, 0,032, ...). If the value is set to **0.0** the display will show --- (function deactivated). Setup of **Peak hold**. In this mode the sensor is waiting for descending signals. If the signal descends the algorithm maintains the previous signal peak for the specified time. After the hold time the signal will drop down to the second highest value or will descend by 1/8 of the difference between the previous peak and the minimum value during the hold time. This value will be held again for the specified time. After this the signal will drop down with

slow time constant and will follow the current object temperature. If the value is set to **0.0** the display will show --- (function deactivated).

40 +optris



Setup of **Valley hold**. In this mode the sensor waits for ascending signals. The definition of the algorithm is according to the peak hold algorithm (inverted). If the value is set to **0.0** the display will show --- (function deactivated).

## Signal graph with P----



- TProcess with Peak Hold (Hold time = 1s)
- TActual without post processing

Operating 41 0.0 Setup of the Lower limit of temperature range. The minimum difference between lower and upper limit is 20 K. If you set the lower limit to a value ≥ upper limit the upper limit will be adjusted to [lower limit + 20 K] automatically. n 500.0 Setup of the Upper limit of the temperature range. The minimum difference between upper and lower limit is **20 K**. The upper limit can only be set to a value = lower limit + 20 K. 0.00 Setup of the Lower limit of the signal output. This setting allows an assignment of a certain signal output level to the lower limit of the temperature range. The adjustment range corresponds to the selected output mode (e.g. 0-5 V). 5.00 Setup of the Upper limit of the signal output. This setting allows an assignment of a certain signal output level to the upper limit of the temperature range. The adjustment range corresponds to the selected output mode (e.g. 0-5 V). Setup of the **Temperature unit** [°C or °F]. 30.0 Setup of the **Lower alarm limit**. This value corresponds to Alarm 1 [▶6.4 Alarms] and is also used as threshold value for relay 1 (if the optional relay board is used). || 100.0 Setup of the Upper alarm limit. This value corresponds to Alarm 2 [▶6.4 Alarms] and is also used as threshold value for relay 2 (if the optional relay board is used). **XHEAD** Setup of the **Ambient temperature compensation**. In dependence on the emissivity value of the object a certain amount of ambient radiation will be reflected from the object surface. To compensate this impact, this function allows the setup of a fixed value which represents the ambient radiation.

42 +optris

If **XHEAD** is shown the ambient temperature value will be taken from the head-internal probe.

To return to **XHEAD** please press **Up** and **Down** together.



Especially if there is a big difference between the ambient temperature at the object and the head temperature the use of **Ambient temperature compensation** is recommended.


Setup of the **Multidrop address**. In a RS485 network each sensor will need a specific address. This menu item will only be shown if a RS485 interface board is plugged in.

**B 9.6** Setup of the **Baud rate** for digital data transfer.

Sighting 43

# 8 Sighting

The CTvideo has an integrated video camera which is using the same optical channel than the IR detector. In addition the sensor has a cross laser aiming which marks the center of the measurement spot at any distance. The combination of video and laser sighting enables a perfect alignment of the sensor to the object.







Do not point the laser directly at the eyes of persons or animals! Do not stare into the laser beam. Avoid indirect exposure via reflective surfaces!

The laser can be activated/ deactivated via the programming keys on the unit or via the software. If the laser is activated a yellow LED will shine (beside temperature display).

At ambient temperatures >50 °C the laser will be switched off automatically.




The laser should only be used for sighting and positioning of the sensor. A permanent use of the laser can reduce the lifetime of the laser diodes and also the measurement accuracy can be affected.

44 \$\phi\text{optris}\$

## 8.1 Focusing and Video Sighting

On the back plane of the sensor you will find a rotary button for focusing of the optics.


To set the focus to the desired measurement distance you have to connect the sensor with a PC using the USB cable. Please start the CompactConnect software. You will see the video beside the temperature-time diagram. The position of the measurement spot is indicated by a circle inside the video picture. The size of this circle is equivalent to the IR spot size.



By turning the rotary button *clockwise* you will change the focus in direction *far*. By turning *counterclockwise* you will change the focus in direction *close*.

After a successful focusing please enter the measurement distance (distance sensor front – object) in the according field in the software (underneath the video picture).

You will find a detailed description of the video settings in the software description which you can call via the menu [?/ Help...].



Sighting 45

## 8.2 Error messages

The display of the sensor can show the following error messages:

#### 1. Digit:

0x No error

1x Head temperature probe short circuit to GND

2x Box temperature too low

4x Box temperature too high

6x Box temperature probe disconnected

8x Box temperature probe short circuit to GND

#### 2. Digit:

x0 No error

x2 Object temperature too high

x4 Head temperature too low

x8 Head temperature too high

xC Head temperature probe disconnected

46 \$\phi\text{optris}\$

# 9 Software CompactConnect

#### 9.1 Installation

Insert the installation CD into the according drive on your computer. If the autorun option is activated the installation wizard will start automatically.

Otherwise please start **CDsetup.exe** from the CD-ROM. Follow the instructions of the wizard until the installation is finished

#### Min. system requirements:

- Windows XP, Vista, 7, 8, 10
- USB interface
- Hard disc with at least 30 MByte free space
- At least 128 MByte RAM
- CD-ROM drive


The installation wizard will place a launch icon on the desktop and in the start menu:

#### [Start]\Programs\CompactConnect.

If you want to uninstall the software from your system please use the uninstall icon in the start menu.



You will find a detailed software manual on the CD.



#### Main Features:

- Alignment of the sensor
- Graphic display for temperature trends and automatic data logging and video snapshot generation for analysis and documentation
- Complete sensor setup and remote controlling
- Adjustment of signal processing functions
- Programming of outputs and functional inputs

## 9.2 Communication Settings

#### Serial Interface

Baud rate: 9,6...115,2 kBaud (adjustable on the unit or via software)

Data bits: 8
Parity: none
Stop bits: 1
Flow control: off

#### Protocol

All sensors of the CTvideo series are using a binary protocol. Alternatively they can be switched to an ASCII protocol. To get a fast communication the protocol has no additional overhead with CR, LR or ACK bytes.

#### **ASCII** protocol

To switch to the ASCII protocol please use the following command:

Decimal: 131
HEX: 0x83
Data, Answer: byte 1

Result: 0 – Binary protocol

1 - ASCII protocol

48 +optris

#### Saving of parameter settings

After power on of the CTvideo sensor the flash mode is active. It means, changed parameter settings will be saved in the internal Flash-EEPROM and will be kept also after the sensor is switched off.

In case settings should be changed quite often or continuously the flash mode can be switched off by using the following command:

Decimal: 112
HEX: 0x70
Data, Answer: byte 1

Result: 0 – Data will not be written into the flash memory

1 - Data will be written into the flash memory

If the flash mode is deactivated, all settings will only be kept as long as the unit is powered. If the unit is switched off and powered on again all previous settings are lost.

The command 0x71 will poll the current status.

You will find a detailed protocol and command description on the software CD CompactConnect in the directory: \Commands.

# 10 Basics of Infrared Thermometry

Depending on the temperature each object emits a certain amount of infrared radiation. A change in the temperature of the object is accompanied by a change in the intensity of the radiation. For the measurement of "thermal radiation" infrared thermometry uses a wave-length ranging between 1 µm and 20 µm. The intensity of the emitted radiation depends on the material. This material contingent constant is described with the help of the emissivity which is a known value for most materials (►11 Emissivity).

Infrared thermometers are optoelectronic sensors. They calculate the surface temperature on the basis of the emitted infrared radiation from an object. The most important feature of infrared thermometers is that they enable the user to measure objects contactless. Consequently, these products help to measure the temperature of inaccessible or moving objects without difficulties. Infrared thermometers basically consist of the following components:

- lens
- spectral filter
- detector
- electronics (amplifier/ linearization/ signal processing)

The specifications of the lens decisively determine the optical path of the infrared thermometer, which is characterized by the ratio Distance to Spot size.

The spectral filter selects the wavelength range, which is relevant for the temperature measurement. The detector in cooperation with the processing electronics transforms the emitted infrared radiation into electrical signals.

50 \$\phi\text{optris}\$

# 11 Emissivity

#### 11.1 Definition

The intensity of infrared radiation, which is emitted by each body, depends on the temperature as well as on the radiation features of the surface material of the measuring object. The emissivity ( $\epsilon$  – Epsilon) is used as a material constant factor to describe the ability of the body to emit infrared energy. It can range between 0 and 100 %. A "blackbody" is the ideal radiation source with an emissivity of 1,0 whereas a mirror shows an emissivity of 0,1.

If the emissivity chosen is too high, the infrared thermometer may display a temperature value which is much lower than the real temperature – assuming the measuring object is warmer than its surroundings. A low emissivity (reflective surfaces) carries the risk of inaccurate measuring results by interfering infrared radiation emitted by background objects (flames, heating systems, chamottes). To minimize measuring errors in such cases, the handling should be performed very carefully and the unit should be protected against reflecting radiation sources.

#### 11.2 Determination of unknown Emissivities

- ► First, determine the actual temperature of the measuring object with a thermocouple or contact sensor. Second, measure the temperature with the infrared thermometer and modify the emissivity until the displayed result corresponds to the actual temperature.
- ▶ If you monitor temperatures of up to 380 °C you may place a special plastic sticker (emissivity dots part number: ACLSED) onto the measuring object, which covers it completely. Now set the emissivity to 0,95

Emissivity 51

and take the temperature of the sticker. Afterwards, determine the temperature of the adjacent area on the measuring object and adjust the emissivity according to the value of the temperature of the sticker.

► Cove a part of the surface of the measuring object with a black, flat paint with an emissivity of 0,98. Adjust the emissivity of your infrared thermometer to 0,98 and take the temperature of the colored surface. Afterwards, determine the temperature of a directly adjacent area and modify the emissivity until the measured value corresponds to the temperature of the colored surface.

CAUTION: On all three methods the object temperature must be different from ambient temperature.

#### 11.3 Characteristic Emissivities

In case none of the methods mentioned above help to determine the emissivity you may use the emissivity tables ► Appendix A – Emissivity Table Metals and Appendix B – Emissivity Table Non Metals. These are average values only. The actual emissivity of a material depends on the following factors:

- temperature
- measuring angle
- geometry of the surface
- thickness of the material
- constitution of the surface (polished, oxidized, rough, sandblast)
- spectral range of the measurement
- transmissivity (e.g. with thin films)

52 optris

# **Appendix A – Emissivity Table Metals**

Material Spectral response		typical Emissivity				
		1,0 µm	1,6 µm	5,1 μm	8-14 μm	
Aluminium	non oxidized	0,1-0,2	0,02-0,2	0,02-0,2	0,02-0,1	
	polished	0,1-0,2	0,02-0,1	0,02-0,1	0,02-0,1	
	roughened	0,2-0,8	0,2-0,6	0,1-0,4	0,1-0,3	
	oxidized	0,4	0,4	0,2-0,4	0,2-0,4	
Brass	polished	0,35	0,01-0,05	0,01-0,05	0,01-0,05	
	roughened	0,65	0,4	0,3	0,3	
	oxidized	0,6	0,6	0,5	0,5	
Copper	polished	0,05	0,03	0,03	0,03	
	roughened	0,05-0,2	0,05-0,2	0,05-0,15	0,05-0,1	
	oxidized	0,2-0,8	0,2-0,9	0,5-0,8	0,4-0,8	
Chrome		0,4	0,4	0,03-0,3	0,02-0,2	
Gold		0,3	0,01-0,1	0,01-0,1	0,01-0,1	
Haynes	alloy	0,5-0,9	0,6-0,9	0,3-0,8	0,3-0,8	
Inconel	electro polished	0,2-0,5	0,25	0,15	0,15	
	sandblast	0,3-0,4	0,3-0,6	0,3-0,6	0,3-0,6	
	oxidized	0,4-0,9	0,6-0,9	0,6-0,9	0,7-0,95	
Iron	non oxidized	0,35	0,1-0,3	0,05-0,25	0,05-0,2	
	rusted		0,6-0,9	0,5-0,8	0,5-0,7	
	oxidized	0,7-0,9	0,5-0,9	0,6-0,9	0,5-0,9	
	forged, blunt	0,9	0,9	0,9	0,9	
	molten	0,35	0,4-0,6			
Iron, casted	non oxidized	0,35	0,3	0,25	0,2	
	oxidized	0,9	0,7-0,9	0,65-0,95	0,6-0,95	

Material Spectral response		typical Emissivity				
		1,0 µm	1,6 µm	5,1 μm	8-14 μm	
Lead	polished	0,35	0,05-0,2	0,05-0,2	0,05-0,1	
	roughened	0,65	0,6	0,4	0,4	
	oxidized		0,3-0,7	0,2-0,7	0,2-0,6	
Magnesium		0,3-0,8	0,05-0,3	0,03-0,15	0,02-0,1	
Mercury			0,05-0,15	0,05-0,15	0,05-0,15	
Molybdenum	non oxidized	0,25-0,35	0,1-0,3	0,1-0,15	0,1	
	oxidized	0,5-0,9	0,4-0,9	0,3-0,7	0,2-0,6	
Monel (Ni-Cu)		0,3	0,2-0,6	0,1-0,5	0,1-0,14	
Nickel	electrolytic	0,2-0,4	0,1-0,3	0,1-0,15	0,05-0,15	
	oxidized	0,8-0,9	0,4-0,7	0,3-0,6	0,2-0,5	
Platinum	black		0,95	0,9	0,9	
Silver		0,04	0,02	0,02	0,02	
Steel	polished plate	0,35	0,25	0,1	0,1	
	rustless	0,35	0,2-0,9	0,15-0,8	0,1-0,8	
	heavy plate			0,5-0,7	0,4-0,6	
	cold-rolled	0,8-0,9	0,8-0,9	0,8-0,9	0,7-0,9	
	oxidized	0,8-0,9	0,8-0,9	0,7-0,9	0,7-0,9	
Tin	non oxidized	0,25	0,1-0,3	0,05	0,05	
Titanium	polished	0,5-0,75	0,3-0,5	0,1-0,3	0,05-0,2	
	oxidized		0,6-0,8	0,5-0,7	0,5-0,6	
Wolfram	polished	0,35-0,4	0,1-0,3	0,05-0,25	0,03-0,1	
Zinc	polished	0,5	0,05	0,03	0,02	
	oxidized	0,6	0,15	0,1	0,1	

54 optris


# **Appendix B – Emissivity Table Non Metals**

Material Spectral response		typical Emissivity				
		1,0 µm	2,2 µm	5,1 μm	8-14 µm	
Asbestos		0,9	0,8	0,9	0,95	
Asphalt				0,95	0,95	
Basalt				0,7	0,7	
Carbon	non oxidized		0,8-0,9	0,8-0,9	0,8-0,9	
	graphite		0,8-0,9	0,7-0,9	0,7-0,8	
Carborundum			0,95	0,9	0,9	
Ceramic		0,4	0,8-0,95	0,8-0,95	0,95	
Concrete		0,65	0,9	0,9	0,95	
Glass	plate		0,2	0,98	0,85	
	melt		0,4-0,9	0,9		
Grit				0,95	0,95	
Gypsum				0,4-0,97	0,8-0,95	
Ice					0,98	
Limestone				0,4-0,98	0,98	
Paint	non alkaline				0,9-0,95	
Paper	any color			0,95	0,95	
Plastic >50 µm	non transparent			0,95	0,95	
Rubber				0,9	0,95	
Sand				0,9	0,9	
Snow					0,9	
Soil					0,9-0,98	
Textiles				0,95	0,95	
Water					0,93	
Wood	natural			0,9-0,95	0,9-0,95	

# **Appendix C – Smart Averaging**

The average function is generally used to smoothen the output signal. With the adjustable parameter time this function can be optimal adjusted to the respective application. One disadvantage of the average function is that fast temperature peaks which are caused by dynamic events are subjected to the same averaging time. Therefore those peaks can only be seen with a delay on the signal output.

The function **Smart Averaging** eliminates this disadvantage by passing those fast events without averaging directly through to the signal output.



Signal graph with Smart Averaging function



Signal graph without Smart Averaging function

# **EU Declaration of Conformity** EG-Konformitätserklärung

Wir / We

Optris GmbH Ferdinand Buisson Str. 14 D-13127 Berlin

erklären in alleiniger Verantwortung, dass declare on our own responsibility that

die Produktserie optris CTvideo the product group optris CTvideo

Appendix D – Declaration of Conformity

den Anforderungen der EMV-Richtlinie 2014/30/EU und der Niederspannungsrichtlinie 2014/35/EU entspricht. entspricht. meets the provisions of the EMC Directive 2014/30/EU and the Low Voltage Directive 2014/35/EU.

Angewandte harmonisierte Normen: Applied harmonized standards:

EMV Anforderungen / EMC General Requirements:

EN 61326-1:2013 (Grundlegende Prüfanforderungen / Basic requirements) EN 61326-2-3:2013

Gerätesicherheit von Messgeräten / Safety of measurement devices:

EN 61010-1:2010 EN 60825-1:2015 (Lasersicherheit / Laser safety)

Dieses Produkt erfüllt die Vorschriften der Richtlinie 2011/65/EU (RoHS) des Europäischen

Parlaments und des Rates vom 8. Juni 2011 zur Beschränkung der Verwendung bestimmter gefährlicher Stöffe in Elektro-und Elektronikgeräten. This product is in conformity with Directive 2011/65/EU (RoHS) of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

Berlin, 04.11.2015

Datum / place,

Dr. Ulrich Kienitz Geschäftsführer / General Manager

**optris**